

Suggested Sampling Sites - Dairy Plants

Tanks

- Tank Valves
- Tank Door Gaskets
- King Gauges
- Agitator Shafts
- Tank Wall



Fillers

- Filler Bowls
- Filler Bowl Cover Gasket
- Mandrels
- Breaker Bars
- Filler Valves
- Underside of Drip Pans/Drip Shields
- Conveyors (Plastic/Chain)
- End of Capper Chute
- Inside Cappers
- Rubber Donuts
- Under Star Wheels & Transfer Plates
- O-rings & Gaskets
- Inside Compressed Air Lines
- Lid Detector Diverter
- Bag-In-Box:
 - Upper valve Stem (Air Valve)

- Filler Valve
- Package Stem Holder

Note:

Focus on irregular or difficult to clean areas, e.g. corners, threads, bad welds, bad gaskets, holes and other obvious microbial harborages.

Check areas frequently touched or handled by employees or equipment manually installed which could results in cross contamination.